


Side Winder Pipe Spreader[™] and Parts List



Side Winder Pipe Spreader Parts



Pipe Spreader Tube

Includes Tube, Cap, and Super Washer (Main Screw not included)




Part #PST30 – tube length 30" Part #PST42 – tube length 42"

Outer Tube Attachment



Includes clevis pin



Part #OTA




Chain Assembly









Chain Assembly – 0208

Includes Chain - 30" Part #CA02

Chain Assembly – 1018

Includes Chain - 60" Part #CA10


Inner Tube Attachment



Part #ITA

Main Screw

Part #MS



FEATURES:

- Reduces man-hours spent removing and installing valves, gaskets, pumps, filters, meters, etc.
- □ Easy to use and fast to install
- Operates with an adjustable wrench (not included)
- □ Use with any type of flange
- Each tool fits a variety of pipe sizes
- Operates horizontally and vertically
- □ 5,000 lb. spreading force

Ordering Information

Side Winder Pipe Spreaders 30"

Operating Span – 5" to 30"

Side Winder Pipe Spreaders 42" Operating Span – 5" to 42"

Model	Pipe Size	Price USD	Model Pip	e Size	Price	e USD
30PS-0208	2" thru 8"	call for price	42PS-0208	2" thru	8″	call for price
30PS-1018	10" thru 18"	call for price	42PS-1018	10" thru	18"	call for price

(925) 516-4204

P. O. Box 887 Pine Grove, CA 95665 (925) 516-4204

sales@a-w-devices.com

Side Winder Pipe Spreader™

Backup Wrench

www.a-w-devices.com







Side Winder



